



## DELUXE Scent Diffuser User Guide

*Pure luxury in a sleek and sophisticated Scent System*



---

291 LAKE AVENUE, ST. JAMES, NEW YORK 11780

P: 631-881-4244 C: 914-643-1273

INFO@SCENTEDINTERIORSBYDESIGN.COM

SCENTEDINTERIORSBYDESIGN.COM

---

## FEATURES:

- *Attractive* 11.5” Brushed Aluminum cannister
- *Lightweight*, mobile
- *Easy to operate* with on/off button on cannister base
- **9 *Misting levels*** to meet your desired scent intensity; (+) to increase level, (-) to decrease
- ***Silent*** and *light misting quickly dissipates* into the atmosphere
- Covers up to **600 square feet**
- Pop-up cannister lid provides easy access to **4oz bottle** of oil
- Built-in timer allows *automatic scheduling* of the unit
- One-year warranty for replacement parts providing Scented Interiors By Design oils are used with the diffuser\*

## SAFETY:

The following basic safety precautions should always be observed.

**Warning:** Fire hazard. Can cause electrical shock or other injury if mishandled, including property damage. In cases of severe weather conditions, unplug your device immediately.

- Ensure wire is in optimal condition.
- Make sure that diffuser is on an even and stable surface.
- Keep away from children, pets, and any open heat sources.
- Do not use diffuser for more than twelve consecutive hours at one time.

\*Note: Our oils are specifically designed to work with each of our scent diffusing systems. Use of any oils other than those made by Scented Interiors By Design may damage the machine's pump and will void the one-year warranty.

## SETTING UP YOUR DELUXE DIFFUSER

1. Find the ideal location for your DELUXE Diffuser.
2. Press down on the atomizer lid until it clicks and pops up.
3. Unscrew the empty glass bottle and replace with your Scented Interiors By Design fragrance oil bottle. Keep the empty bottle for future cleanings.
4. To close the unit, return the atomizer lid to its original position in the diffuser, and gently press down with both hands until you hear it click back into place.

## OPERATIONS

- Power on. Connect with 12V 1A power supply, there will be a “beep.”
- Power off. Press the power button to turn off the machine.
- Intensity setting. The machine has 9 intensity levels, press (+) to increase the intensity and press (-) to decrease the intensity.
- **See last page of guide for misting levels and hourly consumption to gauge your oil use-up rate**
- Power indicator. Indicates the direction of the power supply.



## **MAINTENANCE**

Cleaning the unit should be done before the first use and regularly after every six months, depending on the frequency of use or when changing scents.

- 1.** Press the atomizer lid until it clicks and pops up.
- 2.** Put rubbing alcohol in the empty glass bottle and secure into the diffuser.

DO NOT ADD WATER to the alcohol

- 3.** Reattach the atomizer to the base, ensuring correct alignment.
- 4.** Allow the diffuser to work ten minutes with the rubbing alcohol.

Make certain the unit is unplugged prior to cleaning the interior. To clean the interior, simply separate the atomizer lid from the unit and wipe inside and out with a soft, dry cloth.

Clean the nozzle, sprayer tube and connector using rubbing alcohol. Do not use any corrosive products, detergents, or thinners to clean your diffuser. These products can harm the unit, particularly the plastic parts which are susceptible to corrosion.

## INTENSITY AND OIL CONSUMPTION

<b>GRADE</b>	<b>MISTING(S)</b>	<b>PAUSE(S)</b>	<b>CONSUME(ml/h)</b>
G1	5s	240s	0.03
G2	10s	220s	0.08
G3	15s	200s	0.13
G4	15s	180s	0.18
G5	20s	160s	0.23
G6	20s	120s	0.28
G7	25s	100s	0.33
G8	25s	80s	0.38
G9	25s	60s	0.44