



DELUXE II Scent Diffuser User Guide

Pure luxury in a sleek and sophisticated Scent System



291 LAKE AVENUE, ST. JAMES, NEW YORK 11780

P: 631-881-4244 C: 914-643-1273

INFO@SCENTEDINTERIORSBYDESIGN.COM

SCENTEDINTERIORSBYDESIGN.COM

FEATURES:

- *Attractive 13.25”* Brushed Aluminum cannister available in Silver or Black
- *Lightweight*, mobile, wireless operation once unit is fully charged
- *Easy to operate* with on/off button on cannister base
- Ambient light button for illumination
- **5 Misting levels** to meet your desired scent intensity
- Built-in timer allows *automatic scheduling* of the unit – when powered on, the default setting is 24-hour operation. The timer can be adjusted for 1h, 2h 4h 8h misting
- **Silent** and *light misting quickly dissipates* into the atmosphere
- Covers up to **10,500 cubic square feet**
- Pull-up cannister lid provides easy access to **4oz bottle** of oil
- **Once the diffuser is fully charged, it can operate wirelessly for up to 20 hours**
- One-year warranty for replacement parts providing Scented Interiors By Design oils are used with the diffuser*

SAFETY:

The following basic safety precautions should always be observed.

Warning: Fire hazard. Can cause electrical shock or other injury if mishandled, including property damage. In cases of severe weather conditions, unplug your device immediately.

- Ensure wire is in optimal condition.
- Make sure that diffuser is on an even and stable surface.
- Keep away from children, pets, and any open heat sources.
- Never tip or lay down unit when oil is inside

*Note: Our oils are specifically designed to work with each of our scent diffusing systems. Use of any oils other than those made by Scented Interiors By Design may damage the machine's pump and will void the one-year warranty.

SETTING UP YOUR DELUXE II DIFFUSER

1. Find the ideal location for your DELUXE II Diffuser.
2. Pull up the atomizer lid and take out the diffuser head
3. Unscrew the empty glass bottle and replace with your Scented Interiors By Design fragrance oil bottle. Keep the empty bottle for future cleanings.
4. Put the diffuser head back in the machine

OPERATIONS

- Power on. Connect with 12V power supply, there will be a “beep.”
- Power off. Press the power button to turn off the machine.
- Intensity setting. The machine has 5 intensity levels, press (+) to increase the intensity and press (-) to decrease the intensity.
- **See last page of guide for misting levels and hourly consumption to gauge your oil use-up rate**
- Power indicator. Indicates the direction of the power supply.



MAINTENANCE

Cleaning the unit should be done before the first use and regularly after every six months, depending on the frequency of use or when changing scents.

- 1.** Pull up the atomizer lid and remove the oil bottle; replace with empty maintenance bottle
- 2.** Put rubbing alcohol in the empty glass bottle and secure into the diffuser.
DO NOT ADD WATER to the alcohol
- 3.** Reattach the atomizer to the base, ensuring correct alignment.
- 4.** Allow the diffuser to work ten minutes with the rubbing alcohol.

Make certain the unit is unplugged prior to cleaning the interior. To clean the interior, simply separate the atomizer lid from the unit and wipe inside and out with a soft, dry cloth.

Clean the nozzle, sprayer tube and connector using rubbing alcohol. Do not use any corrosive products, detergents, or thinners to clean your diffuser. These products can harm the unit, particularly the plastic parts which are susceptible to corrosion.

INTENSITY AND OIL CONSUMPTION

GRADE	MISTING(S)	PAUSE(S)	CONSUME(ml/h)
G1	5s	240s	0.05
G2	15s	200s	0.17
G3	20s	160s	0.27
G4	25s	100s	0.49
G5	25s	60s	0.72

CUSTOMIZED

5-35s

60-300s

291 LAKE AVENUE, ST. JAMES, NEW YORK 11780

P: 631-881-4244 C: 914-643-1273

INFO@SCENTEDINTERIORSBYDESIGN.COM

SCENTEDINTERIORSBYDESIGN.COM
